



CENTURION
THE AUTOMATIC CHOICE

www.centsys.co.za

SECTOR

SECTOR™


Sector Traffic Barrier Quick Installation Guide



TRAFFIC
BARRIER



SLIDING GATE
OPERATORS



SWING GATE
OPERATORS



GARAGE DOOR
OPERATORS



REMOTE
CONTROLS



INTERCOMS



KEYPADS



Established 1986

Introduction >>

This quick guide is intended for the experienced installer who has done a SECTOR barrier installation before, knows all the safety aspects required of a site and only needs reminding of the basic steps to follow.



Always ensure that all the safety instructions described in the installation manual are adhered to during and after the installation process is completed.



If in doubt, refer to the installation manual, visit our website, www.CenturionSystems.co.za or call technical support on 0860-CENTURION

Icons used in this guide >>



This icon indicates tips and other information that could be useful during the installation.



This icon denotes variations and other aspects that should be considered during installation.



This icon indicates warning, caution or attention!

Please take special note of critical aspects that *MUST* be adhered to in order to prevent injury.

Required tools and equipment >>

Check that you have all the required tools to complete the installation.

Site considerations >>

Consider the following checklist when determining the safety and suitability of the site:

- Check that all safety and local authority requirements will be met
- Check that the usage (duty cycle) of the site and the length of the boom pole required, are within the barrier specifications
- Check that there is sufficient clearance on the side of the roadway to mount the barrier
- Check that a suitable foundation has been prepared for the barrier
- Check that the fitment of additional safety equipment has been catered for

Select operating mode >>

There are three modes of operation which can be selected, namely Simplex, Complex and PLC.

1. Simplex Mode

Typical application would be the entrance to premises, which is controlled by a guard.

Raising and lowering of the boom pole is done via pushbutton or remote control connected to the memory input (MI). The auto-lower feature can be used to automatically lower the boom pole after an adjustable auto-lower time.

There is one safety input option, which may be used for either an inductive loop detector (recommended) or infrared safety beams. These prevent the boom pole from lowering onto a vehicle. This input may also be used to prevent the boom pole from auto-lowering.

If using the recommended inductive loop detector, the loop must be positioned below the boom pole.

The Sector controller provides a potential-free contact for courtesy or security lights that illuminate automatically when the barrier is operated, and can remain illuminated for an adjustable period of time afterwards.

2. Complex Mode

Typical application is any unmanned entrance, which makes use of any number of different access control devices to raise the boom pole.

In Complex Mode, the boom pole lowers the moment the vehicle has driven over and cleared the closing loop, which is mounted below the boom pole.

Access control devices, including proximity or card readers, keypads, remote controls, etc., are connected to the memory input (MI). The memory input counts and stores each trigger impulse. The boom pole will stay raised until the same number of closing signals are applied to the closing input, such as the closing loop.

CENTURION recommends that an inductive loop detector is used as the closing loop. This also acts as a safety loop while the vehicle is present on the loop detector. As an alternative, but not recommended is to use a set of infrared safety beams. It is recommended that two sets of safety beams are used, which are spaced about 500 millimetres apart.

There is a non-memory input (NMI) to raise the boom pole when activated by a ticket vending machine, pay parking system, etc.

A ticket vend interlock output is available via a potential-free contact to prevent the issuing of tickets if the boom pole is raising or raised. These contacts can also be used as a potential-free contact for courtesy or security lights that illuminate automatically when the barrier is operated and remain illuminated for an adjustable period of time afterwards.

2a. Free-exit (typically applicable to Complex Mode)

It is possible to use the free-exit facility on the controller to automatically raise the barrier for vehicles exiting the parking area or premises.

It is recommended to use an inductive loop detector to activate the free-exit facility. Alternatively, a set of infrared safety beams may be used, but this is not recommended.

The system can be configured for uni-directional traffic with the barrier dedicated as a free-exit barrier. The closing loop will be used to lower the barrier the moment the vehicle has exited.

It can also be configured for bi-directional traffic with the same barrier providing access control for vehicles entering and free-exit for vehicles exiting. The free-exit loop must be mounted close enough to the closing loop so that the vehicle exiting is still present on this loop when it reaches the closing loop. However, these must not be too close together, or magnetic interference will be caused.

3. PLC mode

In this mode of operation, separate inputs are controlled via pushbutton or directly from a third-party programmable logic controller or PC to raise, lower and stop the barrier.

There is one safety input for use with an inductive loop detector or infrared safety beams to prevent the boom



If mounting inductive loops in the ground, please refer to the manufacturer's instructions for full installation details.


Cabling requirements >>

The cable requirements differ according to the mode that you have selected.




- All cables must be routed in conduit unless underground cable is being used
- For the detection of vehicles, Centurion recommends installing ground loops in preference to infrared beams


1. Simplex mode




2. Complex mode (basic)



3a. Free-exit for uni-directional traffic



3b. Free-exit for bi-directional traffic



• **x refers to the distance required between the loops for free-exit**

- Free-exit for uni-directional traffic, x must be greater than 1000mm
- For bi-directional traffic, x must be less than the length of an average motor vehicle (between 1000mm and 2000mm). The exiting vehicle must not leave the free-exit loop before driving onto the closing loop. The barrier will raise when the exiting vehicle drives onto the closing loop.

Legend


1. 220V AC mains cable (3 core LNE 1.5mm² * SWA[†])
 2. Pushbutton control (2 core 0.5mm² multi-stranded)
 3. Infrared safety beams (3 core 0.5mm² multi-stranded)
 4. Optional pillar lights (3 core LNE SWA[†], size according to power requirements)
 5. Inductive loop for closing or safety (1 core 0.5mm² multi-stranded silicone-coated)*
 6. Access control device (3 core 0.5mm² multi-stranded ♦)
 7. Inductive loop for free-exit (1 core 0.5mm multi-stranded - silicone coated)*
- ★ Possibly increase cable thickness if pillar lights are installed
 - † Type of cable must adhere to municipal bylaws but typically SWA (steel wire armoured) cable is recommended. The armouring provides excellent screening, which gives better protection against lightning – earth one end of the screening
 - * Consult manufacturer of loop detector for specific details
 - ♦ Number of cores and type of cable could vary depending on brand of access control system being used

Orientation >>

- It is always recommended to mount the barrier with its access door facing the oncoming traffic. This ensures that if a vehicle accidentally hits the pole, the pole is knocked away from the barrier housing, not back onto the barrier housing, potentially damaging the housing




The **default orientation** is the operator on the **right hand side of the roadway**, with the pole pointing to the left - also referred to as **right hand orientation**





It is possible to change to **left hand orientation** allowing the barrier to be mounted on the left hand side of the roadway with the pole pointing to the right. Please contact CENTURION for details.




Sector installation >>

Enclosure positioning


- Determine correct position for the barrier to be installed



The dotted line denotes recommended dimensions of the concrete foundation




Check orientation of the door




Concrete plinth/foundation

- Prepare hole for concrete foundation
- Install cable conduits, making sure that the conduits exit in cable entry area, leaving approximately 50mm of conduit protruding above the concrete plinth




- Concrete in anchor bolts or fit shield anchor rawl bolts later (size M12 x 70)






The enclosure is clamped down between the holding down bar and the concrete plinth




Fitting the boom pole


- Use the boom pole retainer piece as a ruler to mark a straight line on the boom pole



- Mark and drill the 8.5mm holes in the boom pole according to the measurements provided



- Slide the boom pole retainer piece into the boom pole and push the mounting bolts through the drilled holes
- While holding the boom pole retainer piece in position, fit the boom pole onto the boom coupler
- Fit the M8 spring washers and nuts onto the bolts and tighten



Leveling the boom pole



- Using a 17 spanner, loosen the lock nuts on the adjustment link
- Turn the adjustment link to level the boom pole
- Tighten the lock nuts



Both of the lock nuts will loosen/tighten in the same direction. This might not be the expected direction - if the lock nut does not loosen/tighten try the other direction




As the adjustment link is turned, the boom pole moves up or down. It is helpful to hold the adjustment link with a second spanner during this process



Locked at endstops

- By default the Sector does not lock at the endstops



- In the event of a system failure the boom pole can be raised or lowered by hand



The barrier can be set to Lock mode. Refer to the installation manual for an explanation of Lock mode and how to change between the configurations

Electrical setup


1. Always check that the circuit breaker in the electrical panel is in the OFF position, and that all high voltage circuits (more than 42.4V) are completely isolated from the mains supply before doing any work.
2. Ensure that all low voltage systems (less than 42.4V) are suitably protected from damage, by disconnecting all sources of power such as chargers and batteries before doing any work.
3. All electrical work must be carried out according to the requirements of all applicable local electrical codes. (It is recommended that a licensed electrical contractor perform such work.)

Connect all wiring


1. Connect all cables as required for the specific installation.
2. Ensure all interconnecting cables are securely in place
3. Ensure single phase mains power is connected to the system
4. Switch on the mains (isolator and circuit breaker), make sure that the battery is connected and check that the polarity is correct



Note that the wiring diagrams overleaf begin connection at the **termination board**, and not the controller



Simplex Mode: Option 1 (Recommended) - electrical connections




Option 1

All connections are made to the termination board and NOT the controller (Refer to page 8)

The different inputs to and outputs from the termination board, react according to the following when **Simplex Mode** is selected:

- **MI:** In this mode, the memory input acts simply to raise and lower the boom pole with sequential activations
- **Lower:** A dedicated input to only lower the boom pole
- **Raise:** A dedicated input to only raise the boom pole
- **TVI:** Potential-free contact that can be used for a courtesy or security light. The light illuminates when the barrier is operated and remains switched on for an adjustable period of time after the boom pole has lowered
- **Close (closing loop):** This loop input will act only as a safety loop preventing the boom pole from being lowered onto a vehicle present on the loop

Simplex Mode: Option 2 - electrical connections




Option 2

All connections are made to the termination board and **NOT** the controller (Refer to page 8)

The different inputs to and outputs from the termination board, react according to the following when **Simplex Mode** is selected:

- **Safety Beam:** Infrared safety beams can be used as an alternative to an inductive loop, but not recommended
- **MI:** In this mode, the memory input acts simply to raise and lower the boom pole with sequential activations
- **Lower:** A dedicated input to only lower the boom pole
- **Raise:** A dedicated input to only raise the boom pole
- **TVI:** Potential-free contact that can be used for a courtesy or security light. The light illuminates when the barrier is operated and remains switched on for an adjustable period of time after the boom pole has lowered

Complex Mode: Option 1 (Basic) - electrical connections




Option 1: Basic

All connections are made to the termination board and NOT the controller (Refer to page 8)

The different inputs to and outputs from the termination board, react according to the following when **Complex Mode** is selected:

- **Safety Beam:** Although not recommended, this input can be used if a closing loop detector is not fitted. It is recommended that two safety beams are used, which are spaced about 500 millimetres, horizontally apart
- **MI:** The memory input counts and stores each trigger impulse. The boom pole will stay raised until the same number of closing signals are applied to the closing input, or the auto-lower time expires
- **NMI:** Typically used with ticket vending machines – refer to Option 2
- **Lower:** A dedicated input to only lower the boom pole
- **Raise:** A dedicated input to only raise the boom pole
- **TVI:** Potential-free contact that can be used for a courtesy or security light. The light illuminates when the barrier is operated and remains switched on for an adjustable period of time after the boom pole has lowered
- **Close (closing loop):** The closing loop detector must be fitted. In addition to sensing when the vehicle has passed the barrier for closing purposes, it will act as a safety loop preventing the boom pole from being lowered onto a vehicle present on the loop

Free-exit loop - electrical connections



Option A: Free-exit single lane, unidirectional traffic (Refer to page 3)

All connections are made to the termination board and **NOT** the controller (Refer to page 8)

Please note the following:

- **FRX:** The free-exit loop detector must be fitted. The free-exit loop can be positioned any distance away from the closing loop, typically no less than 1000 millimetres, otherwise it may cause magnetic interference
 - Proceed to Menu level 6.3 and set the free-exit loop direction to UNI
- **Safety Beam:** Although not recommended, this input can be used if a closing loop detector is not fitted. It is recommended that two safety beams are used, which are spaced approximately 500 metres horizontally apart
- **Close (closing loop):** The closing loop detector must be fitted. In addition to raising the boom and sensing when the vehicle has passed the barrier for closing purposes, it will act as a safety loop preventing the boom pole from being lowered onto a vehicle present on the loop




Option B: Free-exit single lane, bi-directional traffic (Refer to page 4)

All connections are made to the termination board and **NOT** the controller (Refer to page 8)

Please note the following:

- **FRX:** The free-exit loop detector must be fitted. The free-exit loop must be mounted typically 1000 - 2000 millimetres from the closing loop. This is to ensure that the vehicle exiting is still present on this loop when it reaches the closing loop. It must not be any closer than 1000 millimetres, otherwise it may cause magnetic interference
 - Proceed to Menu level 6.3 and set the free-exit loop direction to BI
- **TVI:** Potential-free contact that can be used for a courtesy or security light. The light illuminates when the barrier is operated and remains switched on for an adjustable period of time after the boom pole has lowered
- **Close (closing loop):** The closing loop detector must be fitted. In addition to sensing when the vehicle has passed the barrier for closing purposes, it will act as a safety loop preventing the boom pole from being lowered onto a vehicle present on the loop

Complex Mode: Option 2 (Ticket vend) - electrical connections




Option 2: Ticket vending entry points

All connections are made to the termination board and **NOT** the controller (Refer to page 8)

The different inputs to and outputs from the termination board, react according to the following when **Complex Mode** is selected:

- **Safety Beam:** Although not recommended, this input can be used if a closing loop detector is not fitted. It is recommended that two safety beams are used, which are spaced approximately 500 millimetres, horizontally apart
- **MI:** Typically not used
- **NMI:** Non-memory input responds only when the trigger signal to the input is removed. It does not react when the signal is given. Connect to the trigger output from the ticket vending machines
- **Lower:** A dedicated input to only lower the boom pole
- **Raise:** A dedicated input to only raise the boom pole
- **TVI:** Ticket vend interlock is a potential-free output that prevents the ticket vending machine from issuing another ticket until the boom pole is closing or is closed
- **Close (closing loop):** The closing loop detector must be fitted. In addition to sensing when the vehicle has passed the barrier for closing purposes, it will act as a safety loop preventing the boom pole from being lowered onto a vehicle present on the loop

Setting up the limits and features for the Sector barrier



Setting up the limits

When setting up the Sector barrier system via the LCD display, all the steps that have to be followed are clearly provided via the display. It is only necessary to note the following:

- Press and hold the oblong enter (■) button for two seconds to enter setup mode
- If powering up for the first time (ex-factory), select the required profile that will suit the specific region (ZA - for South Africa, CE - for Europe and UL325 - for North America/Canada*)
- With this set, the system will automatically proceed to the limit setup menu. Follow the on-screen instructions to complete the setup procedure
- If powering up at any stage after this, press and hold the oblong enter (■) button for two seconds
- Select the **limits menu** by pressing the oblong enter (■) button. Follow the on-screen instructions to complete the setup procedure

*The profile is compliant with UL325, but the barrier is not certified

Setting up additional features for the Sector barrier

The Sector navigation map that follows, provides the full menu of features that can be set up on the system. A brief explanation of each feature is provided in the section, 'Controller features'.

When setting up additional features, all the steps that have to be followed are clearly provided via the display. It is only necessary to note the following:

- To get into setup mode, press the oblong **enter** (■) button for two seconds and follow the onscreen instructions
- The buttons provided on the controller for navigating the system, are not marked because at each step during the setup, the function given to each button is provided on the display
- When not in setup mode, ie normal mode, the round (●) button is used as a **test** button for operating the system. The up/down buttons are not used unless the diagnostic screens have been selected to appear in normal mode, in which case these buttons allow switching from one screen to the next
- For each feature a factory default setting has been programmed into the controller. Referred to as an **operating standard or profile**, these defaults have been determined to suit the requirements of the specific region where the installation is being carried out. It is only necessary to change a feature where the default does not suit the installation. When selecting any feature in the menu, details of the current setting stored in the controller are displayed
- When selecting any of the features on a new or defaulted controller, the LCD will display the default value

Sector menu navigation map >>



1. Setting limits



1.1. Setup wizard



2. Safety

- 2.1. Collision force.....
 - 2.1.1. Raise collision force
 - 2.1.2. Lower collision force
- 2.2. Collision count
- 2.3. Alarm output
- 2.4. LCK input as ESTOP
- 2.5. External boom status.....
 - 2.5.1. Indicator output
 - 2.5.2. Lowered indication
 - 2.5.3. Partly lowered indication
 - 2.5.4. Lowering indication
 - 2.5.5. Partly raised indication
 - 2.5.6. Raising indication
 - 2.5.7. Raised indication
 - 2.5.8. Unknown indication



3. Auto-lower

- 3.1. Auto-lower status
- 3.2. Auto-lower timer
- 3.3. Auto-lower override
- 3.4. Auto-lower advanced.....
 - 3.4.1. Auto-lower fully raised
 - 3.4.2. Auto-lower partly raised
 - 3.4.3. Auto-lower partly lowered



4. Modes of operation

- 4.1. Operating mode



5. Run profile

- 5.1. Lock boom at endpoints.....
 - 5.1.1. Lock when raised
 - 5.1.2. Lock when lowered
 - 5.1.3. Holding force
- 5.2. Raise when mains fail
- 5.3. Pre-raising delay
- 5.4. Pre-lowering delay
- 5.5. Raising speed
- 5.6. Lowering speed
- 5.7. Ramp-up distance
- 5.8. Ramp-down distance
- 5.9. TRG stop distance
- 5.10. Loop stop distance
- 5.11. Crawl distance
- 5.12. Torque limit



6. Loop detector

- 6.1. ILAC control
- 6.2. Rollback time
- 6.3. FRX loop direction
- 6.4. Inductive loop alarms.....
 - 6.4.1. Presence alarm.....
 - 6.4.1.1. Presence alarm status
 - 6.4.1.2. Presence time
 - 6.4.2. Break-in alarm
 - 6.4.3. Alarm output



7. TVI output

- 7.1. TVI output function
- 7.2. TVI output polarity
- 7.3. Light timer



8. ChronoGuard

- 8.1. Time and date
- 8.2. Time-periods.....
 - 8.2.1. Add Time-period.....
 - 8.2.1.1. Auto function
 - 8.2.1.2. Time-bar function
 - 8.2.2. Delete Time-period
 - 8.2.3. Edit review Time-period
- 8.3. Exclusions.....
 - 8.3.1. Add exclusion.....
 - 8.3.1.1. Auto function
 - 8.3.1.2. Time-bar function
 - 8.3.2. Delete exclusion
 - 8.3.3. Edit review exclusion
- 8.4. Delete all Time-periods and exclusions



9. General settings

- 9.1. Operating standard
- 9.2. Reset options.....
 - 9.2.1. Factory defaults
 - 9.2.2. Delete all remotes
 - 9.2.3. Delete all time periods and exclusions
- 9.3. Diagnostic screen status
- 9.4. Round test button status
- 9.5. Backup eeprom
- 9.6. Restore eeprom



10. Remote controls



Press button of valid transmitter (if menu locked)

- 10.1. Add remotes
- 10.2. Delete remotes
 - 10.2.1. Delete by ID
 - 10.2.2. Delete button
 - 10.2.3. Delete by button
 - 10.2.4. Delete not present
 - 10.2.5. Delete all remotes
- 10.3. Edit remote button
- 10.4. Autolearn remotes
- 10.5. Tx menu locked
- 10.6. Onboard receiver enable/disable

Controller features >>>



Menu 2 - Safety (collision force)

- **Collision force**

The collision force can be set independently for raising or lowering from minimum to maximum in five discrete steps. A sixth step will disable collision sensing entirely, allowing **maximum force** to be achieved. The motor will only shut down when its stall point is reached. Stall level is adjustable, refer to Torque Limit under Menu 5.



This level should only be used if additional safety measures are taken, for example, inductive loops, etc.

The response of the system to a collision will vary, depending on the Operating Standard (eg. CE, UL325*) selected.

*Collision force setting satisfies UL325, but the Sector barrier itself is not certified

- **Collision count**

The number of sequential collisions that the system will allow, before shutting down the controller, if the boom pole does not reach the lowered position. Counter resets each time the boom pole reaches lowered position. A valid trigger input will clear the shutdown.

- **Alarm output**

An alarm is activated if the multiple collision shutdown is triggered. This menu item configures the different alarm outputs.

- **Lck as ESTOP**

Allows the Lck (Holiday Lockout) input to be configured as an emergency stop input.

- **External boom status**

Generates an output indicating specific states of the boom



Menu 3 - Auto-lower

- **Auto-lower status**

If enabled, the boom pole will automatically lower after a preset auto-lower time.

- **Auto-lower time**

The auto-lower time can be set anywhere from 1 to 240 seconds (four minutes).

- **Auto-lower override**

Temporarily turn off auto-lower. Activate and maintain the Memory input for longer than the **auto-lower override time**. Activate Memory input to clear the override.

- **Auto-lower advanced options**

Set the conditions under which the boom pole will auto lower. More than one condition can be selected:

- **Auto-lower on raised** - automatically lower the boom if boom pole is fully raised
- **Auto-lower on partly raised** - automatically lower the boom pole if it has been stopped partially raised
- **Auto-lower on partly lowered** - automatically lower the boom pole if it has been stopped partially lowered



Menu 4 - Modes of operation

Refer to Select operating mode on page 2 for explanation of three different modes of operation available: Simplex, Complex and PLC.



Menu 5 - Run profile

- **Lock boom pole at endpoints:**

- **Lock when raised** - mechanically lock boom pole in raised position. Use manual override key to override
- **Lock when lowered** - as per above for lowered position



The locking endpoints must be accordingly set for locking to take effect. Refer to installation manual

- **Holding force** - force used to automatically hold the boom pole in the raised or lowered position if "lock at endpoints" is **not** selected

- **Raise when mains fail**
If enabled, the boom pole will raise in event of a mains power failure. Boom pole will remain raised until mains power is restored
- **Pre-raising delay**
Allows a delay between a valid trigger signal and the boom pole raising. Can activate warning light during delay if TVI is not selected. (Refer to pre-flash modes of the Courtesy light feature, for more details.)
- **Pre-lowering delay**
Identical to above, except for boom pole lowering.
- **Raising speed**
Sets the maximum raising speed in degrees per second.
- **Ramp-up distance**
Sets the ramp-up distance in degrees.
- **Ramp-down distance**
Sets the ramp-down distance in degrees of travel of the boom pole when stopping.
- **TRG stop distance**
Sets the distance over which a moving boom pole will stop after a trigger signal is received.
- **Loop stop distance**
Sets the distance over which a moving boom pole will stop after a safety input is triggered.
- **Crawl distance**
Sets the final crawl distance in degrees of travel of the boom pole when reaching an endpoint.
- **Torque limit**
Sets the maximum torque delivered by the motor. This is useful in cases where limited push force is required.



Menu 6 - Loop detector

- **ILAC (Inductive Loop Autoclose) Control**
Causes the boom to auto-lower as soon as the closing inductive loop is cleared, ie. the vehicle moves off.
- **FRX (Free-exit) loop direction**
Allows a single access point with bi-directional traffic to make use of a free-exit loop. Due consideration must be given to closing and free-exit loop positioning.
- **Loop alarms**
While the boom pole is lowered, this feature allows the following alarms
 - **Presence alarm** - Activates an alarm if the closing loop has been continuously activated for a predefined time. The alarm will remain activated while the closing loop is activated
 - **Presence time** - The time for which the closing loop must be continuously activated before the alarm is activated
 - **Break-in alarm** - Activates an alarm if the closing loop is activated while the boom is lowered. The alarm remains active while the closing loop is activated, and for a period of 30 seconds thereafter. This time is fixed
 - **Alarm output** - This menu item configures the different alarm outputs



Menu 7 - TVI (Ticket Vend Interlock) output

Configure TVI output for the specific purpose or as a courtesy light. Refer to the glossary at the back of the installation manual for a definition of TVI. If configured as a Courtesy light, light will switch on for a timed period every time the boom is activated.

- **TVI output polarity**
Configure output as a normally-closed (NC) or normally-open (NO) contact.
- **The TVI output when configured to courtesy light time**
The courtesy light time can be set from four seconds to ten hours.
- **The TVI output when configured to light profile**
Select operation of courtesy light according to four different modes



Menu 8 - ChronoGuard (Time-periods)

ChronoGuard (patent pending) allows automatic activation or time-barring (prevented operation) of specific controller inputs, and the time-barring of specified remote control buttons used together with the onboard receiver. The Real Time Clock will keep time for a minimum of one hour without any power.

- **Time-periods**

A Time-period is defined by a start and end date and time. Up to 100 Time-periods can be defined. A Time-period can be set as a once off event, repeated on a weekly or annual basis. The weekly repeat can be chosen to occur on every day of the week, weekdays only, weekends only, or any specific day. The minimum duration of a Time-period is one minute. Once-off Time-periods have the highest precedence, followed by annual and then weekly.

- **Auto functions (Auto-activations)**

Activate automatically any of the following inputs/outputs during a Time-period

Inputs

- Barrier raise
- Barrier lower
- Barrier disable (Lck) - also referred to as Holiday Lockout
- Closing loop (ILD)

Outputs

- Aux Out - this is a switching negative that can be used to drive an external relay for operating any external device
- Aux IO - this is a switching negative that can be used to drive an external relay for operating any external device

- **Time-barring**

Time-barring of inputs is divided into physical inputs and inputs mapped to a remote control button.

The following physical inputs can be time-barred (prevented from operating) during a Time-period:

- Barrier raise
- Barrier lower
- Memory input (MI)
- Non-memory input (NMI)
- Barrier disable (Lck)

The following physical outputs can be time-barred (prevented from operating) during a Time-period:

- TVI (configured as a courtesy light relay)

The following remote control inputs can be time-barred (prevented from operating) during a Time-period:

- Barrier raise
- Barrier lower
- Memory input (MI)
- Non-memory input (NMI)
- Barrier disable (Lck)



Time-barring of a NOVA rolling code transmitter (Keeloq™ encryption) is specified at the time of coding the transmitter into the system. Once an RF input is defined as time-barred, any time-barred transmitter associated with that input will be time-barred during the relevant Time-period. If a physical or RF input is currently time-barred, any attempt to activate it will be acknowledged by a short beep of the onboard buzzer. The input, however, will not activate.

- **Exclusions**

Exclusions are used to prevent scheduled Time-periods from occurring at specific times (eg. public holidays). While time-barring can be used to achieve a similar end, exclusions can also be used to exclude time-barring itself. Each exclusion consumes one Time-period. Exclusions have the highest precedence, followed by time-barring and then auto functions.



Menu 9 - General settings

- **Operating standard**
Configure the controller to conform to the specific regions standard - e.g. UL325 or CE.
- **Reset options**
 - **Factory defaults** - Restore only defaults for the operating standard / profile chosen, no other settings affected
 - **Delete all remotes** - Delete all the remotes stored in the system; no other settings affected
 - **Reset all** - Clears the controller completely as per an off-the-production-line unit



Boom pole end-of-travel limits are not affected by any reset.

- **Diagnostic screen**
Allows a diagnostic screen to be displayed.
- **Round test button**
Disables operation of the round test button on the controller.




Menu 10: Remote controls

Learn up to 500 Centurion NOVA remote control (Keeloq™ encryption) transmitter buttons. Using one button as a shift button, each transmitter can operate up to six functions. Each transmitter learned into the system is assigned a unique transmitter ID. When adding transmitters, it is recommended that a record be kept of the ID number allocated by the system to each respective transmitter and the person to whom the transmitter is given. This is necessary should selective deletion be required at a later stage.

- **Press button of valid transmitter**
If the **remote controls menu** has been locked as discussed later, only by pressing a button of a transmitter learned into the system, can this **remote controls menu** be accessed.
- **Add remote**
Any button can be set to control the memory, non-memory, raise boom pole, lower boom pole and holiday lockout inputs.
- **Delete remote**
Transmitters can be deleted at any stage according to one of the following:
 - **Delete remote by ID** - Where a record of the unique ID has been kept, delete transmitter according to this
 - **Delete remote button** - Clear operation of a button on a particular transmitter
 - **Delete remote by button** - Delete a transmitter that is present
 - **Delete not present** - Allows a Time-period to be set in hours. Any remotes which have not been used in the Time-period will be deleted
 - **Delete all remotes** - Clear the entire remote memory
- **Edit remote button**
Move the function from one button to another. The transmitter must be present.
- **Autolearn**
Allows a Time-period to be set, during which any specific button will be learned to a specific function when it is pressed. The function will also be activated when the button is pressed. After the Time-period has expired autolearn is disabled, and no further buttons will be learned.
- **Tx menu locked**
Lock the "Remote controls" menu and prevent unauthorized addition of new transmitters. Once enabled, the "Remote controls" menu can only be accessed by pressing a valid transmitter button.

Diagnostic LEDs

The Sector controller has a series of diagnostic LEDs which indicate the state of the inputs. Normally open inputs are indicated by a red LED, and normally closed inputs by a green LED. An illuminated red LED indicates that the signal is present (e.g. barrier raise pressed), while a non-illuminated green LED indicates that the signal is absent (i.e. IRB broken)



Sector barrier status LED

Off	Barrier is lowered
On	Barrier is partially or fully raised
Continuous slow flash	Barrier is raising
Continuous fast flash	Barrier is lowering
One flash every two seconds	Pillar light override is activated
Two flashes every two seconds	No mains present
Three flashes every two seconds	Battery voltage is low
Four flashes every two seconds	Multiple collisions have occurred

LCD display

The Sector controller's LCD display shows valuable information regarding the status of the system.

1. Battery icon

Indicates the state of charge of the battery.

- Four solid bars = full capacity
- Two solid bars = 50% capacity
- No solid bars, with the icon flashing = battery empty

2. Mains icon

Displays the presence/absence of mains voltage:

- Plug solid = mains present and battery charging
- Plug hollow and flashing = No mains present and battery not charging

3. Auto-lower information

- Displays the state of the auto-lower function
- Displays off if auto-lower is not selected
- OVR if auto-lower is overridden, and the remaining auto-lower time if auto-lower is active

4. Pillar light/TVI information


- Displays the remaining light time if courtesy light mode is selected
- Pre-flashing mode is displayed if pre-flash is selected
- LIT will be indicated if the pillar light has been turned on permanently
- TVI will be indicated if the TVI output has been configured

5. Onboard receiver information

Displays the current input being activated by the onboard receiver.

6. Status information

Displays useful information regarding the status of the barrier.



Buzzer feedback

A warning buzzer will sound (where applicable) as per the table below:

Inhibitor name	Priority	Number of beeps	Fault type	Barrier continues to operate	User can correct error
Break-in alarm	1	Continuous tone for 30 seconds	Alarm	N/A	N/A
Presence alarm	2	Continuous tone until ILD is cleared	Alarm	N/A	N/A
Battery low	3	3 beeps periodically for 30 seconds	Power system fault	Yes*	Yes
Multiple collision	4	Periodic until condition is cleared by user (500/500ms)	Collision	No	Yes
Auxiliary overload	5	5 beeps periodically for 30 seconds	Hardware	No	No
Holiday Lockout	6	1 beep periodically for 30 seconds	User	No	Yes
Emergency stop	7	1 beep periodically for 30 seconds	User	No	Yes
Time-barring	8	1 beep periodically for 5 seconds	User	No	Yes
No limits set	9	3 short beeps for 5 seconds	Lost	No	Yes
Mains failure	10	2 beeps periodically for 30 seconds	Power system fault	Yes	Yes
ILD broken	11	1 beep periodically for 30 seconds	User	No	Yes
DOSS disconnected	12	5 beeps periodically for 30 seconds	Hardware	No	No
Fuse blown	13	5 beeps periodically for 30 seconds	Hardware	No	Yes
Motor disconnected	14	5 beeps periodically for 30 seconds	Hardware	No	Yes
Bridge damaged	15	5 beeps periodically for 30 seconds	Hardware	No	No
Barrier stalled	16	4 beeps periodically for 10 seconds	Collision	No	Yes

Factory defaults schedule >>

When selecting any feature, the factory default is given on the LCD display. Contact CENTURION for more details.

Fault-finders guide >>

Refer to the installation manual for the detailed fault-finders guide.

Installation handover >>

Explain to the user how to safely operate the barrier, the different safety features and the manual override.



Sharecall number 0860-CENTURION

(Please note that this number is only applicable if dialed from within South Africa)

Please visit www.centsys.co.za

for more information on the world-class products manufactured by
Centurion Systems, as well as for details of your nearest agent

Centurion Systems (Pty) Ltd Head Office

Unit 13 Northlands Production Park
Epsom Avenue
Johannesburg
Northriding
2196

PO Box 506
Cramerview
2060
South Africa

Tel +27 (0)11 699 2400
Fax +27 (0)11 704 3412 or (0)11 462 6669
(Please omit the (0) when dialing from outside South Africa)

South African Branches and Regional Distributors

Bloemfontein	(0)51 430 0870
Cape Town	(0)21 510 0951
Durban	(0)31 701 9583
East London	(0)43 743 4923
Johannesburg Central/West Rand	(0)11 699 2400
Johannesburg East Rand	(0)11 397 6401
Kimberly	(0)53 832 3231
Nelspruit	(0)13 752 8074/5
Port Elizabeth	(0)41 581 6994/5
Pretoria	(0)12 349 1745
Vereeniging	(0)16 422 5667



DR: 1187.D.01.0001 3 RD: 25.02.2010 MAP: 0000.D.01.0008 1

www.centsys.co.za

© 2010 Centurion Systems (Pty) Ltd.

E&OE Centurion Systems (Pty) Ltd reserves the right to change any product without prior notice

