

### **Kocom Wireless Intercom Programming Procedure.**

1. Make sure the handset and gate station are close to one another.
2. Apply power to both handset and gate station.
3. Push and hold GATE RELEASE button on handset and CALL button on gate station simultaneously for 3 seconds.
4. Green and Blue LED's will flash twice simultaneously to confirm programming procedure.
5. Release buttons and test unit.