E.T 500 SLIDER LIMIT SETUP

- 1 All dipswithes off
- 2 Place jumper across PROG J pins
- 3 Press/Release SET button
- 4 Gate will close / open /close
- 5 PCB will beep to confirm set up

Note If gate opens first, change motor wires

AUTO CLOSE

- 1 Place jumper across PROG J pins
- 2 Switch dipswitch 1 ON
- 3 Press/Hold SET button
- 4 PCB will beep (1 beep = 1 Sec)
- 5 Release SET button at required time
- 6 Switch dipswitch 1 OFF and then ON again

Note Default is 15 seconds

PED OPENING

- 1 Place jumper across PROG J pins
- 2 Switch dipswitch 2 ON
- 3 Press/Release SET button Gate will close and re-open
- 4 Press/Release SET button to stop gate at required pedestrian opening distance
- 5 Press/Hold SET button
- 6 PCB will beep (1 beep = 1 Sec)
- 7 Release SET button at required time
- 8 Switch dipswitch 2 OFF

ERASE ALL REMOTES

- 1 Power down
- 2 Short all THREE prog pins
- 3 Power up
- 4 RX led will flash then stay on permanently.
- 5 Remove SHORT and POWER
- 6 Re-apply power

REMOTE PROG FOR FULL OPENING

- 1 Press/Hold TX button
- 2 While holding, SHORT BT and middle pin
- 3 RX led will flash to confirm success
- Note Up to 25 remotes can be programmed

REMOTE PROG FOR PED OPENING

- 1 Press/Hold TX button
- 2 While holding, SHORT PED and middle pin
- 3 RX led will flash to confirm success
- Note Up to 5 remotes can be programmed

LOAD SETTING

- 1 Turn load pot very slowly
- 2 1 beep is minimum and 5 beeps is maximum