



Manufacturers & Wholesalers to the security industry


Dts-16 Roller Motor Installation Guide.

READ IN CONJUNCTION WITH THE DTS-12 ROLLER MOTOR INSTALLATION MANUAL

Bolt motor onto centre shaft. Drill hole through garage door shaft to line up with shaft bolt on Dts-16 motor.



Bolt the outside wheel of the Dts-16 to the garage door using suitable bolts e.g.: Tek screws, Bolt and nut.



Using the same procedure as the Dts-12 motor, adjust the limits but loosening the thumb screw and revolving the brass collar. Do not forget to tighten the thumbscrew after adjusting the limits.

